North Florida Communications

LG ipLDK-60
HTP Programming

You can determine how *you* receive intercom calls from your co-workers.

Choose from:

Handsfree Mode- Reply handsfree or lift the handset to converse. The calling party can hear any conversation in progress

Tone Mode- Intercom calls ring. Lift the handset or press "Speaker" to converse.

Private Mode- You can hear the calling party, but they cannot hear you. Lift the handset or press "Speaker" to converse.

HTP Programming Steps

1) Select "Menu". This is the up-arrow key on the navigation wheel at the bottom of the phone.

2) Press "1" for "Basic Program"

3) Press "3" for H/T/P Program

4) Press the "Next" soft-key until you reach the desired mode

5) Press the "OK" soft-key to save your selection

The LCD will display how your phone is programmed. (H) for Handsfree, (T) for Tone Ring Mode or (P) for Private Mode.