



# North Florida Communications

[www.northfloridacommunications.com](http://www.northfloridacommunications.com)

[www.ournewphone.com](http://www.ournewphone.com)

## LG IPECS

### 9200 Series Phones

#### Programming Flexible Buttons



- 1) Press the [Trans/PGM] button.
- 2) Press the Flexible Button you wish to program.
- 3) To program a Direct Station Select button simply dial the 3 Digit Extension number you wish to program, or select a feature code from the chart below.
- 4) Press [Hold/Save] to store your selection
- 5) Return to Step 2 to program another Flexible Button or press "Speaker" to quit.

## Flexible Numbering Plan

Attribute	Value	Attribute	Value
Intercom Call	100 ~ 199	Internal Page Zones	501 ~ 510
Internal All Call Page	543	Meet Me Page	544
External Page Zone	545		
External All Call Page	548	All Call Page	549
SMDR Account Code Enter	550	Flash Command To CO Line	551
SLT Last Number Redial	552	Do-Not-Disturb(DND)	553
Call Forward	554	Speed Dial Program	555
Activate Message Wait/Call Back	556	Message Wait/Call-Back Answer	557
SLT Speed Dial Access	558	DND/FWD Cancel	559
SLT CO System Hold	560	SLT Program Mode Access	561
Attendant Unavailable	562	AME Feature	564
Alarm Reset	565	Group Call Pick-Up	566
Universal Night Answer	567	Account Code With Bin	568
Walking COS	569	ACD Agent ON/OFF Duty	571
ACD Supervisor Login	572	ACD Supervisor Logout	573
ACD Help Code	574	ACD Call In Queue Display	575
ACD Supervisor Status	576	ACD Supervisor Monitor	577
ACD Reroute Queued Call Answer	578	ACD Reroute Queued Call No Answer	579
Camp-On Answer	600	Call Park Locations	601 ~ 610

Station Group Pilot Number	620 ~ 659	Station User VSF Features Access	66
Call Coverage Ring	67	Direct Call Pick-Up	7
Access CO Group	801 ~ 820	Access Individual CO/IP	8801 ~ 8842
Access Held CO/IP	8*	Access Held Individual CO/IP	8#
Access CO In First CO Group	9	Attendant Call	0
VM MSG Wait Enable	0	VM MSG Wait Cancel	0
Door Open 1	##1		
MCID Request	*0	Unsupervised Conference Timer Extend Code	##
PTT Group Login/Logout	#0	ACD Agent Primary Login	581
ACD Agent Primary Logout	582	ACD Agent Secondary Login	583
ACD Agent Secondary Logout	584	Wrap up End	585
TNET CM LOGIN/OUT	586	ENTER INTO CONF-ROOM	59
ENTER INTO CONF-GROUP	68	STATION ICR	587
PICKUP GROUP PICK-UP	588	EMERGENCY PAGE	589
Speed Dial	[SPEED]+Number	Last Number Redial(LNR)	[REDIAL]
Save Number Redial	[SAVE]	Remote Mex Control	580
Agent ON/OFF Duty In ALL GRP	58*		

### Station User Program Codes

11x	Intercom Differential Ring
12x	CO Line Differential Ring
13	Intercom Answer Mode (1: HF/2: TONE/3: PV)
14x	Call Coverage Attribute Setting
15x	Station Ring Download
21	Knock Down Station COS
22	Restore Station COS
23	Walking COS
24	ICR Scenario
25	LIP Keypad Stat
26	Call Profile
30	VM Mobile Notify
31	Message Retrieve Method
32	Message Retrieve Example
33	User Authorization Code Registration
34	DID Call Wait

35	Message Wait in Executive/Secretary pair
36	Send SMS Message
37	Register Mobile Extension
38	Make Mobile Extension active
39	Register Mobile Extension CLI
41	Set Wake-Up Time
42	Set Wake-Up Time
51XX	Custom/Pre-select Message Display (XX = 00-20)
52	Register Custom Message (Message 00)
53	Active Conference Room
54	Deactive Conference Room
55	Monitor Conference Group
57	{Call Log Display} Button Assignment
61	Headset/Speakerphone Mode
62	Change Ring Mode
71	LCD Display Mode
72	Version Display

73	Background Music
74	Station User Name Registration
75	Display Phone IP Address
76	Change Phone IP Address
77	Display Phone MAC Address
78	Change Mode
79	Display Phone Version
7*	Display Serial number/Package for SMEMU
80	{Record} Button Assignment - With Voice Mail
81	{CLIR} Button Assignment
82	{COLR} Button Assignment
83	{ATD DND} button assignment
84	{Account Code} Button Assignment
85	{LOOP} Button Assignment
86	{ATD Intrusion} Button Assignment
87	{INTERCOM} Button Assignment
88	{Camp-on} Button Assignment
89	{Send Keypad Facility IE} Button

	Assignment
8#	{OHVO} Button Assignment
90	{SPEED} Button Assignment
91	{CONFERENCE} button assignment
92	{CALLBACK} button assignment
93	{DND} button assignment
94	{FLASH} button assignment
95	{MUTE} button assignment
96	{MONITOR} button assignment
97	{REDIAL} button assignment
98	{CALL FORWARD} button assignment
99	{PTT} button assignment
9*XX	{In-Room Indication} button assignment (XX = 01-10)
*7	Forced FWD To Dest
*8	Register Bluetooth
*9	Bluetooth Usage
*0	Hotdesk Login
**	Hotdesk Logout



# North Florida Communications

[www.northfloridacommunications.com](http://www.northfloridacommunications.com)

[www.ournewphone.com](http://www.ournewphone.com)

---